


Complete Instructional Guide



TOOLS NEEDED FOR ASSEMBLY









PARTS LIST CONFIRM ALL PARTS ARE PRESENT BEFORE STARTING INSTALLATION



PLANT SUPPORT UPRIGHT



PLANT SUPPORT CROSSBAR



CLEVIS PIN



COTTER PIN




TEK SCREWS (SELF TAPPING)

FOLLOW INSTRUCTIONS BELOW


STEP #1

The Plant Support System will run the length of the bench. Take one Plant Support Upright and place it 2.0" from the end of the bench. Using two Tek Screws, secure the Plant Support Upright to the aluminum side rail of the bench. Do this on all four corners of the bench.



STEP #2

The remaining Plant Support Uprights should be placed on center at each bench leg, on both sides of the bench.







FOLLOW INSTRUCTIONS BELOW (CONT.)

STEP #3

Once all the Plant Support Uprights are secured to the bench, each pair of uprights will get its own Plant Support Crossbar. These are secured to the uprights by means of a Clevis Pin and a Cotter Pin.

NOTE: Modify the crossbar height based on the height of the plant.





CONGRATULATIONS YOUR PLANT SUPPORT SYSTEM IS COMPLETE!

